

## REPLACEMENT PARTS




Figure 55 – Cabinet Replacement Parts

NUMBER	DESCRIPTION	PART NUMBER	NUMBER	DESCRIPTION	PART NUMBER
1	EXHAUST ASSY	7850P-021	11	AIR PRESSURE SWITCH	7850P-047
2	CASE	7850P-044	12	DISPLAY BRACKET	7850P-065
3	DOOR ASSY	7850P-025	13	DISPLAY	7850P-057
3-1	FRONT COVER	7850P-062	14	CONTROL (RT Models)	7850P-058
3-2	DISPLAY PANEL BRACKET	7850P-024	15	CONTROL BRACKET	7850P-066
3-3	DISPLAY PANEL	7850P-023	16	ROCKER SWITCH	7850P-059
4	IGNITION TRANSFORMER	7850P-045	17	FLOW CONTROL VALVE	7850P-053
5	GAS INLET NIPPLE	7850P-043	18	WATER INLET VALVE ASSY	7850P-018
6	OVERHEAT SENSOR	7850P-050	18-1	WATER INLET VALVE BODY	7850P-067
7	DHW SUPPLY PIPE ASSY	7850P-020	18-2	WATER INLET SENSOR	7850P-015
7-1	DHW SUPPLY PIPE	7850P-063	18-3	WATER INLET FILTER	7850P-017
7-2	WATER OUTLET SENSOR	7850P-019	18-4	WATER INLET FILTER CAP	7850P-016
8	N/A	N/A	19	CASE BRACKET (RIGHT OR LEFT)	7850P-068
9	SIPHON ASSY	7850P-014	20	INTAKE AIR ASSY	7850P-022
10	SIPHON AIR PRESSURE HOSE	7850P-064			

Table 35 – Cabinet Replacement Parts




Figure 56 – Heat Exchanger Replacement Parts

NUMBER	DESCRIPTION	PART NUMBER	NUMBER	DESCRIPTION	PART NUMBER
31	HEAT EXCHANGER ASSY	7850P-032	36	FLAME DETECTOR SENSOR	7850P-031
31-1	EXHAUST PIPE ASSY (UP)	7850P-033	37	MIXING VALVE	7850P-054
31-2	EXHAUST TEMPERATURE SENSOR	7850P-070	38	H/X TEMPERATURE SENSOR	7850P-081
31-3	EXHAUST GASKET 1	7850P-071	39	H/X OVERHEAT SWITCH	7850P-051
31-4	EXHAUST PIPE ASSY (DOWN) W/ CONDENSATE COLLECTOR PAN	7850P-034	40	DHW OUTLET PIPE	7850P-049
31-5	EXHAUST H/X GASKET	7850P-072	41	WATER PIPING CLIP	7850P-055
31-6	N/A	N/A	42	DHW INLET PIPE	7850P-048
32	FAN ASSEMBLY	7850P-006	43	CERAMIC HEATER	7850P-076
32-1	FAN	7850P-002	44	GAS VALVE PIPE (UPPER)	7850P-039
32-2	BLOWER O-RING	7850P-003	45	GAS VALVE PIPE (LOWER)	7850P-040
32-3	AGM (ACTUATOR)	7850P-004	46	GAS VALVE ADAPTER (STRAIGHT)	7850P-077
33	SILENCER ELBOW	7850P-036	47	GAS VALVE ASSY W/ PLUG	7850P-078
34	SILENCER BODY	7850P-035	47-1	GAS VALVE	7850P-012
35	BURNER ASSY	7850P-011	47-2	GAS VALVE PLUG	7850P-013
35-1	BURNER HEAD	7850P-007	48	GAS VALVE ADAPTER (90 DEGREE)	7850P-079
35-2	IGNITION ROD BRACKET	7850P-010	49	GAS VALVE BRACKET	7850P-080
35-3	IGNITION ROD	7850P-008	50	BOTTOM HEAT EXCHANGER BRACKETS (LEFT)	7850P-028
35-4	BLOWER HEAD BRACKET	7850P-074	51	BOTTOM HEAT EXCHANGER BRACKETS (RIGHT)	7850P-091
35-5	OVERHEAT SENSOR (BURNER)	7850P-009	52	TOP HEAT EXCHANGER BRACKETS	7850P-082
35-6	METAL FIBER ASSY	7850P-075			

Table 36 – Heat Exchanger Replacement Parts